

Terminal Settings for NetTerm Terminal

Press Alt and Esc to enter setup Menu

F1

Columns = 80	Cursor = Blink Block	Screen Saver = Off
Lines = 25	Background = Dark	Page Length = 1 * lines
Auto Page = Off	Width Change Clear = Off	ANSI Reverse = Off
Display = LCD		

F2

Personality = Console ANSI	Enhance = Off	Status Line = Off
Scroll Speed = Jump	Auto Scroll = On	End of Line Wrap = On
Rcvd CR = CR	Monitor = Off	Attribute = Char

F3

Keyclick = Off	Key Repeat = Off	Xmt Limit = None
Margin Bell = Off	Language = US	Keycode = ASCII
NRC = Off	Bell Volume = 3	NUM Start = On
Del Keypad = Dot/Del		

F4

Baud Rate = 19200	Data/Stop = 8/1	Parity = None
Rcv Handshake = Xon/Xoff	Xmit Handshake = Xon/Xoff	Comm Mode = FDX
XPC Handshake = On	Printer = Off	

F5 through F11 do not require any Changes.

Press F12 to exit, Press the space bar to save the changes and press F12 again to exit.